

# ATS OWNER'S MANUAL



ArcTiv Logo is a registered trademark of ArcTiv Technology Co., Ltd.

© Copyright 2020 ArcTiv Technologies, LLC, USA. All rights reserved. No part of this document may be reproduced in any way without the expressed written approval of ArcTiv Technologies, LLC.

## Content

<b>1 ATS Overview .....</b>	<b>3</b>
<b>2 Functional Description.....</b>	<b>3</b>
<b>3 Application.....</b>	<b>3</b>
<b>4 Product Schematic.....</b>	<b>4</b>
<b>5 Mounting Method .....</b>	<b>5</b>
<b>6 Hardware Introduction .....</b>	<b>5</b>
<b>7 Hyper Terminal User Guide .....</b>	<b>8</b>
<b>8 Performance Parameters .....</b>	<b>17</b>
<b>9 Accessories List.....</b>	<b>18</b>
<b>10 Warranty Policy .....</b>	<b>18</b>

## 1. ATS Overview

The ArcTiv Automatic Transfer Switch (ATS) is a highly reliable switch that provides redundant power to connected equipment. If the primary power source becomes unavailable, the ATS will seamlessly switch to the secondary power source automatically. ATS products are offered in basic and intelligent types. The user can upgrade the basic ATS to an intelligent model by inserting a hot swappable Network Management Card, which enables the user to monitor and manage the ATS via web interface or SNMP browser.



## 2. Functional Description

1. **Switching:** Switch over between Source A and Source B automatically, transfer time  $10 \leq 16$ ms
2. **Monitoring:** Load current; input and output voltage; source A and source B power input; device status
3. **Remote Controlling:** Switch over between Source A and Source B. Set the threshold for the total load current and input voltage.
4. **Automatic Alarms:** Triggers when thresholds are exceeded
5. **System Default Alarming:** When total load current/voltage exceed the limit value, when only single source power up when automatically switching occur
6. **Alarming Method:** Buzz and flesh alarming. E-mail alarming(only intelligent type)
7. **Log Recording:** record and save the log of the device running and alarming information. User can view and export the data history
8. **System Support:** Single user operation system, support software update
9. **Account Management:** set the authorization of the account
10. **Access Method:** Ethernet connection, web interface through IE browser, SNMP(V1), access and control through standard network management, Serial Connection (Modbus protocol by defaulted)
11. **System Settings:** system time, lock devices, voltage threshold, transfer time.

## 3. Applications

ATS series product are compliant to the physical requirements of server racks, network cabinets, etc. ATS series products are in accordance with the regulation of RoHS.


## 4. Product Schematic



1. Alarm: the port of buzz and flash, used to connect to external annunciator
2. RS485: Serial communication port, connect the device to local PC
3. LED screen: display the current; voltage; IP address and hardware version
4. Reset: Rest button
5. Preference: to select the preferred power source
6. Input indicator of source B
7. Output indicator of source B
8. RUN: Operation indicator
9. NET: Ethernet Port
10. Press to select data: To view power date and information
11. Preference indicator of source A
12. Preference indicator of source B
13. Input indicator of source A
14. Output indicator of source A

## 5 Mounting Method

Horizontal rack mounting. Choose a suitable installation location for the ATS which occupies 1 or 2 RMU rack space. Insert cage nuts on each EIA vertical mounting rail in your rack. Align the bracket's mounting holes with the cage nuts. Insert and tighten the screws.



## 6 Hardware Introduction

### 6.1 Self-check when powering on

The buzzer beeps once when powering on. The LED indicator always lights on, digital screen display load current after self-checking **8.8.8**.

### 6.2 Operation status viewing

Through the "press to select date" button, the user can view the voltage, IP address (only intelligent type) and device version number.

### 6.3 Select the preferred power source

Use the Preferred button to select the primary power source. The user has 3 options:

1. Set the source A as the preferred power source
2. Set the source B as the preferred power source
3. Leave open

The corresponding indicator will always light on if a selection was made. If not, the two indicators will remain off. Please note that with the intelligent ATS Lock function, if the user cannot complete the setting above, please log on to the Web interface to unlock.

### 6.4 Reset operation

To manually reset the ATS, Press the Reset button to reset the device without affecting the outlet status.

### 6.5 Restore to factory settings

Press and hold the “press to select data” button for 6 seconds, the LED screen will display “IP” when released. Then press Reset to restore the default IP 192.168.1.163, User name and password.

6.6 Serial connection

Using the supplied serial cable, insert the RJ45 connector to the RS485 communication port and connect the other end to the serial port of a local PC.

6.7 External speaker connection

Use the supplied terminal to connect the external speaker. The max voltage of 50VDC and load current of 5A

6.8 Ethernet connection (only intelligent type)

Using the supplied network cable, connect one side to the NET port of the device and the other end to the network.

6.9 The software or hardware update method




6.9.1 Save the software update file **ATS.hex** provided by supplier to the local PC.




philips\_flash\_ut...  
WinRAR ZIP 压缩文件  
2,058 KB

6.9.2 Open the software update file **philips\_flash\_ut...**, double-click the setup.exe file to install

6.9.3 Run the software as below when the installation is finished.





6.9.4 Insert the RJ45 connector of the update signal cable into the RS485 port of the ATS front panel, connect the other end to the port COM1 of local PC.





6.9.5 Select the serial port are using **COM1**, other items please refer to the above pictures.

6.9.6 Click the  from  and submit the file  to the frame

6.9.7 Power on the ATS.

6.9.8 Click ,  will be displayed on the interface if read success. If not, please double-check the cable connection and communication port.

6.9.9 Click ,  will be displayed on the interface if erase success, if not, please double-check the cable connection and communication port

6.9.10 Click ,  will be displayed on the interface if loading success. If not, please double check the cable and communication port

6.9.11 Power off the ATS.


6.9.12 Power on on the ATS, digital screen will display the new hardware version number, it can perform normal communication after software update success.

## 7 Hyper Terminal User Guide


7.1 Using the supplied serial cable, connect one end to the RS485 port and the other end to serial port of local PC. Running the Hyper terminal program (like Windows Hyper terminal), click:

**Start → Programs → Accessories → Communication → Hyper Terminal**

7.2 The dialog box as below will pop up if it is the first time that the PC has run the Hyper Terminal




7.3 Enter one or several numbers at random when it requires your area code, for instance 0755 and click OK.





7.4 The link description window will pop-up as below:




7.5 Enter a Device Name (such as ATS) and click OK.




7.6 Select the COM port that will be used and click OK.

- 7.7 Set the baud rate of ATS as 19200 and enter configuration information for data bits, parity and flow control as provided below. Then click OK.




- 7.8 If it is not the first time that the PC has run the Hyper Terminal, it will go directly to the window as in item 4 of this section. Follow instructions 4 – 7 and enter the Hyper Terminal monitoring interface as below:




## 7.9 Setup ASCII Code


7.9.1 Click the file in the main menu and select attributes or click on the icon  directly.



7.9.2 Click on ASCII Setup



7.9.3 Tick the boxes as window above, then click the OK button and return to the monitoring interface.



## 7.10 Press Enter, following message will be displayed in the interface if setting success.

**Main Menu**


1-Device Manager

2-Set Current And Voltage Limit

3-System Time

## 7.11 View the ATS status.

Enter 1 and press Enter, the ATS status will be displayed in the interface as below:

**Device Manager:** Device Manager**Source A Voltage:** The voltage of the source A**Source B Voltage:** The voltage of the source B**Output Current:** The output current**Selected Source:** The current input power is source B**Preferred Source:** The preferred input power is source A**Back To The Main Power Supply Time:** Re-transfer time is 10 seconds**1- Set The Preferred Source:** Enter 1 then press Enter to set the primary power source**2- Set Switchover Time:** Enter 2 then press Enter to set the Re-transfer time**0- Main Menu:** Enter 0 then press Enter to return to main menu

7.12 Set the preferred power input, follow up the path step by step:

**Main Menu => 1 Device Manager => 1**

Set the Preferred Source, it will show the following window

```

ATS - HyperTerminal
File Edit View Call Transfer Help
Back To The Main Power Supply Time: 10
1- Set The Preferred Source
2- Set Switchover Time
0- Main Menu
Select And Press ENTER Key Or Press ENTER Key To Refresh
> 1
----- Set The Preferred Source -----
1- Source A
2- Source B
3- None
Select The Preferred Source And Press ENTER Key
> -
Connected 0:12:09 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo

```

7.12.1 Enter the corresponding code, for example:

Enter 1 then press Enter to select input A as the preferred power input. The interface will return to the Device Manager interface. See the window below for reference.

**Preferred Source:** Source A means that input A was select as the primary power source.

```


ATS - HyperTerminal
File Edit View Call Transfer Help
----- Device Manager -----
Source A Voltage: 226 Volt
Source B Voltage: 225 Volt
Output Current : 0.0 Amp
Selected Source : Source B
Preferred Source: None
Back To The Main Power Supply Time: 10
1- Set The Preferred Source
2- Set Switchover Time
0- Main Menu
Select And Press ENTER Key Or Press ENTER Key To Refresh
>
Connected 0:13:06 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo

```

7.13 Set the Re-transfer time:


**Main Menu => 1 (Device Manager) => 2 (Set Switchover Time)**

Enter the preferred value, then press Enter. The Re-transfer time ranges from 10 to 60 seconds. The ATS will transfer to the preferred input power after defined time when the user gives the order to transfer or the preferred input line recovers from a power failure.



7.14 Define the threshold voltage and current.


### Main Menu =>2 (Set Current And Voltage Limit)




Enter corresponding number to re-define the item that user want to change.

- Select 1 to set the minimum value of current to alarm
- Select 2 to set the maximum value of current to alarm
- Select 3 to set the minimum value of voltage to alarm
- Select 4 to set the maximum value of voltage to alarm.

For example, if the user wants to change the value of the minimum current alarm, enter 1 then press Enter:




Enter the preferred value, then press Enter. Return to Set Current And Voltage Limit interface.

7.15 Setup the system time of ATS. **Main Menu =>3 (System Time)**


```

ATS - HyperTerminal
File Edit View Call Transfer Help
----- Main Menu -----
1- Device Manager
2- Set Current And Voltage Limit
3- System Time
Select And Press ENTER Key Or Press ENTER Key To Refresh
> 3
----- System Time -----
1- System Date(yyyy/mm/dd): 2010/12/29
2- System Time(hh:mm:ss) : 9:37: 5
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> _
Connected 0:17:31 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo

```


7.15.1 Select 1 to modify date. **Main Menu =>3 (System Time) => 1**


```

ATS - HyperTerminal
File Edit View Call Transfer Help
----- Main Menu -----
1- Device Manager
2- Set Current And Voltage Limit
3- System Time
Select And Press ENTER Key Or Press ENTER Key To Refresh
> 3
----- System Time -----
1- System Date(yyyy/mm/dd): 2010/12/29
2- System Time(hh:mm:ss) : 9:37: 5
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> 1
Input The Date(yyyy/mm/dd):
Connected 0:18:02 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo

```

Enter the correct date format in the window. For example: 2010/07/22




```

ATS - HyperTerminal
File Edit View Call Transfer Help
1- System Date(yyyy/mm/dd): 2010/12/29
2- System Time(hh:mm:ss) : 9:37: 5
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> 1
Input The Date(yyyy/mm/dd): 2010/07/22
----- System Time -----
1- System Date(yyyy/mm/dd): 2010/ 7/22
2- System Time(hh:mm:ss) : 9:38:47
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> _
Connected 0:19:20 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo


```

The above window shows that the setting is a success.

7.15.2 Input the Time **Main Menu=>3 (System Time) =>2**

```
ATS - HyperTerminal
File Edit View Call Transfer Help
----- System Time -----
1- System Date(yyyy/mm/dd): 2010/ 7/22
2- System Time(hh:mm:ss) : 16:18: 4
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> 2
Input The Time(hh:mm:ss): _
Connected 0:01:22 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo
```

Enter the correct time form in the window. For example: 11:15:23



```
ATS - HyperTerminal
File Edit View Call Transfer Help
1- System Date(yyyy/mm/dd): 2010/ 7/22
2- System Time(hh:mm:ss) : 9:38:47
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> 2
Input The Time(hh:mm:ss): 11:15:23
----- System Time -----
1- System Date(yyyy/mm/dd): 2010/ 7/22
2- System Time(hh:mm:ss) : 11:15:23
0- Main Menu
Select And Press ENTER Key To Change Time Or Press ENTER Key To Refresh
> _
Connected 0:20:28 Auto detect 19200 8-N-1 SCROLL CAPS NUM Capture Print echo
```

The above window shows that the setting is a success.



## 8. Performance Parameters

Function	ITEM		Performance Parameters			
Input	Power Input		2 power input			
	Rating Voltage		220VAC			
	Voltage Range		180VAC~260VAC			
	Rating Power		50/60HZ			
	Frequency Range		Rating power $\pm$ 5HZ			
	Overload & Breaker		Optional, one of them can be added (not both)			
	Surge Protector					
	Max Load Current		16A, 32A			
	1U	Power input method		Plug	Load current	
		1	IEC 320 C20 x 2		16A	
2		Cable	IEC60309x2	16A		
2U		1	Cable	IEC60309x2 32A		
Output	1U	Power output		Connector	Output	Outlet Quantity
		1	Socket		IEC320 C13	6
					IEC320 C19	2
		2	Cable	IEC60309 16A		1
	2U	1	Socket		IEC320 C13	12
					IEC320 C19	4
		2	Cable	IEC60309/32A		1
	Max Load Current		16A, 32A			
Communication/alar m port	Logic Port		Headphone (1) to connect the external speaker			
	Network Port		RJ45 (1, Intelligent Models)			
	Serial Communication Port		RJ45 (1)			
	Phone Alarming Port		RJ11, 1 (Intelligent ATS)			
Transfer	Transfer Polarity		L、N (Double Polarity)			
	Transfer Time		10 $\leq$ 16ms			
Display	Output Current		Digital Display	LED, three-digit, red		
			Display Resolution	100mA $\pm$ 1%+1D		
	Output voltage		Digital Display	LED, three-digit, red		
			Display Resolution	1V $\pm$ 1% +3D		
IP Address		Left Circulation Display, (intelligent ATS)				
Mounting	Horizontal Rack Mount		1U or 2U			
Case color	Color		Black			
Accessories	Brackets		One Set			
	Network Cable		2M, Blue (1 piece)			
	User manual		One set (Include a CD)			
Working Temp	-5~40°C					
Storage Temp	-20~70°C					
Op. Humidity	30%~90%, Non-Condensing					

## 9. Accessories List

- 1 x Serial Cable
- 1 x Network Cable (only intelligent ATS)
- 4 x  $\phi 6 \times 16$ mm cross bolt
- 1 x User Manual and CD

Optional Accessories:

- Circuit Breaker
- Surge Protection Module

## 10. Warranty Policy

The product is guaranteed for **2 years (24 months)** from the date of purchase. We will repair or replace the defective products covered by the warranty. If product has already exceeded the warranty period or the problem are caused because of illegal operation, a corresponding fee will be charged. The following cases are not covered by the warranty:

4. Problems caused because of improper maintenance
5. Problems caused because of unauthorized changes, modifications or improper use
6. The device is not used or stored in the appropriate physical environment

Repair notice:

1. Make sure to use protective hard carton packaging when arranging the shipment to repair. Problem occurring during the shipment is not covered by the warranty.
2. Include a description of the problem and the operation process.
3. Customer to pay for the shipping cost as well as the customs duties.
4. Please list your name, address and phone number so that we can contact you at any time.