



OWNER'S MANUAL

EZ-PDU's



EZ-PDU's

TABLE OF CONTENTS

1. PRODUCT OVERVIEW	3
2. SAFETY INSTRUCTIONS	4
3. NETWORK METERING	5
3.1 NETWORK METER FUNCTIONS	5
3.2 INITIALIZATION	6
3.3 HARDWARE SETTINGS	6
3.4 DAISY CHAIN SETTINGS	7
3.5 SOFTWARE OVERVIEW	7
3.6 SNMP ACCESS	12
3.7 TELNET ACCESS	16
4. SPECIFICATIONS	17
5. WARRANTY	18

1. PRODUCT OVERVIEW

ArcTiv EZ-PDU's are designed for easy configuration to meet the exact application requirements. Optional local or network meters can be added during deployment or field-upgraded. Each PDU supports:

- Customizable with international and local plugs and outlets to the exact application requirement
- Compatible with DCIM's via ModBus and SNMP communication
- Field upgradable network module

Benefits include:

Power Monitoring	Energy and power monitoring with 1% accuracy
Alarms	User-defined thresholds automate actions before overload
Remote Monitoring	Securely access real-time power consumption
Environmental Monitoring	Connects to rack sensors for system management
Daisy Chain	Connect up to 5 PDU's with a single IP address to reduce cabling costs
Field Upgradeable	Upgrade the network module
Full Range	International and local plugs and outlets
Easy Installation	Tool-less 0U mounting compatible with Server and Network Racks
Safe Operation	Locking C13 outlets prevent accidental removal of power cables

Power & Environment Monitoring



Hot-swap Network Meter



Environmental Sensors

Remote Management

Item	Name	Status	Unit
1	Line 1 Current	0	A
2	Line 1 Voltage	214	V
3	Line 1 Power	0	kW
4	Line 1 Energy	26.4	kWh
5	Temperature	0	°C
6	Humidity	0	%

Daisy Chain up to 5 PDU's

Item	Name	Status	Min	Max	Unit
1	Line 1 current	0	0	32	Amps
2	Line 2 current	0	0	32	Amps
3	Line 3 current	0	0	32	Amps

Item	Name	Status	Min	Max	Unit
1	Line 1 voltage	214	0	280	Volts
2	Line 2 voltage	214	0	275	Volts
3	Line 3 voltage	213	0	275	Volts

Item	Name	Status	Min	Max	Unit
1	Temp (°C)	0	0	40	°C
2	Hum (%)	0	0	98	%

Automatic Email and Alarms

2. SAFETY INSTRUCTIONS

- Keep the Basic & Metered PDU's in a controlled indoor environment, away from moisture, temperature extremes, flammable liquids and gasses, conductive contaminants, dust and direct sunlight.
- Before installing the PDU's, check the existence of earth wires before the power supply.
- Check that the marked nominal voltage is the same as the service voltage in the country or region.
- Check that the supply is properly grounded and the power cord, plug and socket are in good condition.
- Check that the max power of the load equipment is less than the max output power of the PDU.
- Do NOT install the PDU where excessive moisture is present.
- Only use supplied brackets for mounting
- For PDU's with surge protection modules, check the following 3 indicators
 - Red Light: Absence of earth wire of the power supply
 - Yellow Light: Live wire (L) and Neutral Wire (N) are not in the correct positions.
 - Green Light: When disabled, means the failure of the lightning protection circuit.
- For pluggable equipment, the socket-outlet shall be installed near the equipment and easily accessible.
- For Pluggable or permanently connected equipment:
 - Short Circuit / Overcurrent Protection: Branch circuit breaker or branch fuse, rating, number of poles, special characteristics
- Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended. Do not use this equipment in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide.

3. NETWORK METERING

The network metered EZ-PDU's are able to monitor the following parameters:

- Input voltage (V)
- Total load current (A)
- Total power (kW)
- Energy consumption (kWh)
- The environment inside the enclosure

Target power ranges for the EZ-PDU's include:

- Single Phase (90VAC – 240VAC) up to 63A
- Three-Phase (270VAC – 400VAC) up to 32A

3.1 NETWORK METER FUNCTIONS



1. **Screen:** TFT screen;
2. **Indicator:** Run, kWh, Alarm
3. **NET:** Ethernet port
4. **SER:** Daisy-chain port
5. **LINK:** Daisy-chain port
6. **MENU:** Menu Key
7. **UP:** Function set key
8. **DOWN:** Position selection key
9. **RESET:** Restart button
10. **T/H:** Temperature/Humidity sensor port

Function of Network Meter

Item	Function	Description
RUN	Run indicator	Flash frequency is 1 second
KWH	kWh indicator	Flash frequency depends on the load
ALM	Alarm indicator	Light is on if there is an alarm occurring
NET	Ethernet port	LAN/WAN Ethernet communication port
SER	Daisy-chain port	RS-485 daisy-chain communication port
LINK	Daisy-chain port	RS-485 daisy-chain communication port
MENU	Menu key	To view the LCD displayed information, light up the LCD background, or save the configuration, use the MENU button as an ENTER key. Restore to factory settings: Hold the MENU key and press the RESET button to restore. Mute alarming: Press and hold the MENU key for 4 seconds to turn On/Off the alarm
UP	Function set key	Light up the LCD background, set the Master or Slave address cord, the maximum threshold of voltage, current, temperature and humidity from 0 to 9
DOWN	Position selection key	Light up the LCD background, select the address code, threshold of voltage, current, temperature and humidity
RESET	Restart button	Restart the device
Screen	View the states	Display the power and environment status
T/H	Sensor port	Connect the external T/H sensor

3.2 INITIALIZATION

When powering on the EZ-PDU's, the RUN indicator will flash and the PDU works normally after initializing the LED indicator and TFT screen. Below are the LCD displaying content introductions from DC, single phase and three phase power sources. The user can navigate these screens by pressing the MENU button.

Screen	1-Phase	3-Phase	DC
1	Current (A), Voltage (V), Power (kW), Energy (kWh)	L1: Current (A), Voltage (V), Power (kW), Energy (kWh)	Current (A), Voltage (V), Power (kW), Energy (kWh)
2	Temp & Humidity (from External Sensor)	L2: Current (A), Voltage (V), Power (kW), Energy (kWh)	Temp & Humidity (from External Sensor)
3	Baud Rate	L2: Current (A), Voltage (V), Power (kW), Energy (kWh)	Baud Rate
4	IP Address	Temp & Humidity (from External Sensor)	IP Address
5	Voltage and Current Threshold	Baud Rate	Voltage and Current Threshold
6	Temp & Humid Threshold	IP Address	Temp & Humid Threshold
7	N/A	L1: Voltage and Current Threshold	N/A
8	N/A	L2: Voltage and Current Threshold	N/A
9	N/A	L3: Voltage and Current Threshold	N/A
10	N/A	Temp & Humid Threshold	N/A

3.3 HARDWARE SETTINGS


Setting	Action
Address Code	To locate the address code from the LCD screen, press the DOWN key to select the master or slave address code and press UP key to set the value from 0 to 4.
Current or Voltage Threshold	To locate the threshold setting page, press the DOWN key to select the item, then press the UP key to set the threshold value, the allowed maximum current is 32A and maximum voltage is 276VAC
Restore to Factory Default	Press and hold the MENU key when powering on or Hold the MENU key to press the RESET button.
Mute the Alarm	Press and hold the MENU key for 5-6 seconds when there is an alarm to turn on/off. When the alarm is turned on, an ON indicator will be displayed in red on the screen, When the alarm was turned off, an OFF indicator will be displayed in red on the screen

Note: All above settings must be saved by pressing the MENU key, and the settings will take effective after the beep sound, otherwise, the device will beep but without saving the settings.

3.4 DAISY CHAIN SETTINGS


Serial Daisy-chain mode

Set one EZ-PDU as the master, and the remainder as the slave units. The maximum daisy-chain is 4 PDU's



Ethernet Daisy-chain mode

Connect the each EZ-PDU to the port from the HUB and connect the Net port from HUB to the internet. There are no PDU quantity limits. Connect the Master net port with the computer net port, then access via IE.



3.5 SOFTWARE OVERVIEW

User can access the Network Metered EZ-PDU's through a WEB interface, SNMP (v1) or Telnet command console.

Web Browser Access

User can access the Network Metered EZ-PDU's via web browser through the IP address. The login window is illustrated below. The factory default username is 'admin', the password is 'admin'.

The screenshot shows a web browser login interface. It contains two input fields: 'User Name:' with the text 'admin' entered, and 'Password:' with five dots representing a masked password. Below these fields is a 'Login' button.

Device State (Home Page)

Displays the current, voltage, power and energy consumption of the Network Metered EZ-PDU.

- Select drop-down list **PDU: Master** ▼ view the power date of the Master unit or Slave units.
- Select drop-down list **Line 1** ▼ to view the power date of L1, L2 or L3 (Three phase models only)

Device Show Information

PDU: **Master** ▼

Input : AC

Input Line: **Line 1** ▼

L1 0 A

214 V 0 kW

26.4 kWh

Item	Name	Status	Unit
1	Line 1 Current	0	A
2	Line 1 Voltage	214	V
3	Line 1 Power	0	kW
4	Line 1 Energy	26.4	kWh
5	Temperature	0	℃
6	Humidity	0	%

Threshold Setting

Set the threshold of current, voltage, temperature and humidity.

- Input Current Range:
 - Single Phase: 0-63A
 - Three Phase: 0-32A
- Input Voltage Range: 170-276VAC
- Temperature range: 0-45℃
- Humidity range: 0-99%

Current Settings

Item	Name	State(A)	Min(A)	Max(A)	Save
1	Line 1 current	0	0	32	Save
2	Line 2 current	0	0	32	Save
3	Line 3 current	0	0	32	Save

Voltage Settings

Item	Name	State(V)	Min(V)	Max(V)	Save
1	Line 1 voltage	214	0	286	Save
2	Line 2 voltage	214	0	275	Save
3	Line 3 voltage	213	0	275	Save

Sensor Settings

Item	Name	Status	Min	Max	Save
1	Temp (℃)	0	0	40	Save
2	Hum (%)	0	0	99	Save

Device Settings

The Device Settings are as follows:

- Device Name: Fill the device name.
- Web server port
- Work model: Revise master and slave mode, to set slave1, 2..... (Virtual Value: 1-4)

Energy Setting

Clear energy line1 : Click **Apply** button.

(The same operation for Line 2 and Line3 for 3phase products.)

User Settings

User can change the user name and password (the max. character length for each is 16 digits).

Network

System IP	92.168.1.163	(factory default)
Subnet Mask	255.255.255.0	
Default Gateway	192.168.1.1	
DNS	202.96.128.86	(factory default)

Note: Restarting software is necessary after a modification of the network settings. Go to "Restart" section for instructions.

SNMP/Telnet

The default Get community and Set community is "public" and "private". User can modify according to the specific application. Fill in the trap address of SNMP management platform and the trap alarm will be sent automatically. There are 2 Trap addresses.

- Telnet settings
- Select from "Enable" or "Disable" to configure the Telnet feature, the default state is enabled.

Note: Restarting software is necessary after SNMP setting. Go to "SNMP Access (V1)" section for instructions.

E-mail Alarm Settings

Set the SMTP including SMTP account, password, SMTP server and port, then save. Click Testing and fill in the testing email address. If the test email is received, the setting is effective. See below interface.

The screenshot shows the 'E-mail Alarm Settings' page. On the left, a vertical menu lists various settings categories, with 'E-mail Alarm Settings' selected and highlighted in blue. The main area is titled 'SMTP Settings' and includes the following fields and buttons:

- SMTP Account:
- Password:
- SMTP Server:
- Port:
- Send to:
- Testing:
- Save:

Restart

Select Activity: User can restart the software or restore to factory default settings by clicking “Save”. When the Network Module buzzes, the software restart is successful.

Note: Press and hold the MENU button when powering on to restore to factory settings.

The screenshot shows the 'System Settings' page. On the left, a vertical menu lists various settings categories, with 'Restart' selected and highlighted in blue. The main area is titled 'System Settings' and includes the following elements:

- Select Activity:
- Save:

3.6 SNMP V1 ACCESS

Parameter	OID	Instructions
deviceName	1.3.6.1.4.1.534.6.6.8.1.1	the name of the master unit
deviceDescription	1.3.6.1.4.1.534.6.6.8.1.2	the information of the master unit
deviceVersion	1.3.6.1.4.1.534.6.6.8.1.3	the software version of master unit
ipAddr	1.3.6.1.4.1.534.6.6.8.1.4	the IP address of master unit
macAddr	1.3.6.1.4.1.534.6.6.8.1.5	the Mac address of master unit
s1macAddr	1.3.6.1.4.1.534.6.6.8.1.6	the Mac address of slave unit 1
s2macAddr	1.3.6.1.4.1.534.6.6.8.1.7	the Mac address of slave unit 2
s3macAddr	1.3.6.1.4.1.534.6.6.8.1.8	the Mac address of slave unit 3
s4macAddr	1.3.6.1.4.1.534.6.6.8.1.9	the Mac address of slave unit 4
mInputVoltage	1.3.6.1.4.1.534.6.6.8.2.1	the average voltage of master unit
s1InputVoltage	1.3.6.1.4.1.534.6.6.8.2.2	the average voltage of slave unit 1
s2InputVoltage	1.3.6.1.4.1.534.6.6.8.2.3	the average voltage of slave unit 2
s3InputVoltage	1.3.6.1.4.1.534.6.6.8.2.4	the average voltage of slave unit 3
s4InputVoltage	1.3.6.1.4.1.534.6.6.8.2.5	the average voltage of slave unit 4
mVoltageA	1.3.6.1.4.1.534.6.6.8.2.6	the voltage of phase 1 from master unit
s1VoltageA	1.3.6.1.4.1.534.6.6.8.2.7	the voltage of phase 1 from slave unit 1
s2VoltageA	1.3.6.1.4.1.534.6.6.8.2.8	the voltage of phase 1 from slave unit 2
s3VoltageA	1.3.6.1.4.1.534.6.6.8.2.9	the voltage of phase 1 from slave unit 3
s4VoltageA	1.3.6.1.4.1.534.6.6.8.2.10	the voltage of phase 1 from slave unit 4
mVoltageB	1.3.6.1.4.1.534.6.6.8.2.11	the voltage of phase 2 from master unit
s1VoltageB	1.3.6.1.4.1.534.6.6.8.2.12	the voltage of phase 2 from slave unit 1
s2VoltageB	1.3.6.1.4.1.534.6.6.8.2.13	the voltage of phase 2 from slave unit 2
s3VoltageB	1.3.6.1.4.1.534.6.6.8.2.14	the voltage of phase 2 from slave unit 3
s4VoltageB	1.3.6.1.4.1.534.6.6.8.2.15	the voltage of phase 2 from slave unit 4
mVoltageC	1.3.6.1.4.1.534.6.6.8.2.16	the voltage of phase 3 from master unit
s1VoltageC	1.3.6.1.4.1.534.6.6.8.2.17	the voltage of phase 3 from slave unit 1
s2VoltageC	1.3.6.1.4.1.534.6.6.8.2.18	the voltage of phase 3 from slave unit 2
s3VoltageC	1.3.6.1.4.1.534.6.6.8.2.19	the voltage of phase 3 from slave unit 3
s4VoltageC	1.3.6.1.4.1.534.6.6.8.2.20	the voltage of phase 3 from slave unit 4
mCurrentA	1.3.6.1.4.1.534.6.6.8.3.1	the current of phase 1 from master unit
s1CurrentA	1.3.6.1.4.1.534.6.6.8.3.2	the current of phase 1 from slave unit 1
s2CurrentA	1.3.6.1.4.1.534.6.6.8.3.3	the current of phase 1 from slave unit 2
s3CurrentA	1.3.6.1.4.1.534.6.6.8.3.4	the current of phase 1 from slave unit 3
s4Current A	1.3.6.1.4.1.534.6.6.8.3.5	the current of phase 1 from slave unit 4
mCurrentB	1.3.6.1.4.1.534.6.6.8.3.6	the current of phase 2 from master unit
s1CurrentB	1.3.6.1.4.1.534.6.6.8.3.7	the current of phase 2 from slave unit 1
s2CurrentB	1.3.6.1.4.1.534.6.6.8.3.8	the current of phase 2 from slave unit 2
s3CurrentB	1.3.6.1.4.1.534.6.6.8.3.9	the current of phase 2 from slave unit 3
s4CurrentB	1.3.6.1.4.1.534.6.6.8.3.10	the current of phase 2 from slave unit 4
mCurrentC	1.3.6.1.4.1.534.6.6.8.3.11	the current of phase 3 from master unit
s1Current C	1.3.6.1.4.1.534.6.6.8.3.12	the current of phase 3 from slave unit 1
s2CurrentC	1.3.6.1.4.1.534.6.6.8.3.13	the current of phase 3 from slave unit 2
s3CurrentC	1.3.6.1.4.1.534.6.6.8.3.14	the current of phase 3 from slave unit 3

s4Current C	1.3.6.1.4.1.534.6.6.8.3.15	the current of phase 3 from slave unit 4
mActPowerA	1.3.6.1.4.1.534.6.6.8.4.1	the active power of phase 1 from master unit
s1ActPowerA	1.3.6.1.4.1.534.6.6.8.4.2	the active power of phase 1 from slave unit 1
s2ActPowerA	1.3.6.1.4.1.534.6.6.8.4.3	the active power of phase 1 from slave unit 2
s3ActPowerA	1.3.6.1.4.1.534.6.6.8.4.4	the active power of phase 1 from slave unit 3
s4ActPowerA	1.3.6.1.4.1.534.6.6.8.4.5	the active power of phase 1 from slave unit 4
mActPowerB	1.3.6.1.4.1.534.6.6.8.4.6	the active power of phase 2 from master unit
s1ActPowerB	1.3.6.1.4.1.534.6.6.8.4.7	the active power of phase 2 from slave unit 1
s2ActPowerB	1.3.6.1.4.1.534.6.6.8.4.8	the active power of phase 2 from slave unit 2
s3ActPowerB	1.3.6.1.4.1.534.6.6.8.4.9	the active power of phase 2 from slave unit 3
s4ActPowerB	1.3.6.1.4.1.534.6.6.8.4.10	the active power of phase 2 from slave unit 4
mActPowerC	1.3.6.1.4.1.534.6.6.8.4.11	the active power of phase 3 from master unit
s1ActPowerC	1.3.6.1.4.1.534.6.6.8.4.12	the active power of phase 3 from slave unit 1
s2ActPowerC	1.3.6.1.4.1.534.6.6.8.4.13	the active power of phase 3 from slave unit 2
s3ActPowerC	1.3.6.1.4.1.534.6.6.8.4.14	the active power of phase 3 from slave unit 3
s4ActPowerC	1.3.6.1.4.1.534.6.6.8.4.15	the active power of phase 3 from slave unit 4
mAppPowerA	1.3.6.1.4.1.534.6.6.8.5.1	the apparent power of phase 1 from master unit
s1AppPowerA	1.3.6.1.4.1.534.6.6.8.5.2	the apparent power of phase 1 from slave unit 1
s2AppPowerA	1.3.6.1.4.1.534.6.6.8.5.3	the apparent power of phase 1 from slave unit 2
s3AppPowerA	1.3.6.1.4.1.534.6.6.8.5.4	the apparent power of phase 1 from slave unit 3
s4AppPowerA	1.3.6.1.4.1.534.6.6.8.5.5	the apparent power of phase 1 from slave unit 4
mAppPowerB	1.3.6.1.4.1.534.6.6.8.5.6	the apparent power of phase 2 from master unit
s1AppPowerB	1.3.6.1.4.1.534.6.6.8.5.7	the apparent power of phase 2 from slave unit 1
s2AppPowerB	1.3.6.1.4.1.534.6.6.8.5.8	the apparent power of phase 2 from slave unit 2
s3AppPowerB	1.3.6.1.4.1.534.6.6.8.5.9	the apparent power of phase 2 from slave unit 3
s4AppPowerB	1.3.6.1.4.1.534.6.6.8.5.10	the apparent power of phase 2 from slave unit 4
mAppPowerC	1.3.6.1.4.1.534.6.6.8.5.11	the apparent power of phase 3 from master unit
s1AppPowerC	1.3.6.1.4.1.534.6.6.8.5.12	the apparent power of phase 3 from slave unit 1
s2AppPowerC	1.3.6.1.4.1.534.6.6.8.5.13	the apparent power of phase 3 from slave unit 2
s3AppPowerC	1.3.6.1.4.1.534.6.6.8.5.14	the apparent power of phase3 from slave unit 3
s4AppPowerC	1.3.6.1.4.1.534.6.6.8.5.15	the apparent power of phase 3 from slave unit 4
mEnergyA	1.3.6.1.4.1.534.6.6.8.6.1	the power consumption of phase 1 from master unit
s1EnergyA	1.3.6.1.4.1.534.6.6.8.6.2	the power consumption of phase 1 from slave unit 1
s2EnergyA	1.3.6.1.4.1.534.6.6.8.6.3	the power consumption of phase 1 from slave unit 2
s3EnergyA	1.3.6.1.4.1.534.6.6.8.6.4	the power consumption of phase 1 from slave unit 3
s4EnergyA	1.3.6.1.4.1.534.6.6.8.6.5	the power consumption of phase 1 from slave unit 4
mEnergyB	1.3.6.1.4.1.534.6.6.8.6.6	the power consumption of phase 2 from master unit
s1EnergyB	1.3.6.1.4.1.534.6.6.8.6.7	the power consumption of phase 2 from slave unit 1
s2EnergyB	1.3.6.1.4.1.534.6.6.8.6.8	the power consumption of phase 2 from slave unit 2
s3EnergyB	1.3.6.1.4.1.534.6.6.8.6.9	the power consumption of phase 2 from slave unit 3
s4EnergyB	1.3.6.1.4.1.534.6.6.8.6.10	the power consumption of phase 2 from slave unit 4
mEnergyC	1.3.6.1.4.1.534.6.6.8.6.11	the power consumption of phase 3 from master unit
s1EnergyC	1.3.6.1.4.1.534.6.6.8.6.12	the power consumption of phase 3 from slave unit 1
s2EnergyC	1.3.6.1.4.1.534.6.6.8.6.13	the power consumption of phase 3 from slave unit 2
s3EnergyC	1.3.6.1.4.1.534.6.6.8.6.14	the power consumption of phase 3 from slave unit 3
s4EnergyC	1.3.6.1.4.1.534.6.6.8.6.15	the power consumption of phase 3 from slave unit 4

mSensorStatus	1.3.6.1.4.1.534.6.6.8.7.1	the sensor connection status from master unit (0: No sensor connected 1: Sensor connected)
s1SensorStatus	1.3.6.1.4.1.534.6.6.8.7.2	the sensor connection status from slave unit 1 (0: No sensor connected 1: Sensor connected)
s2SensorStatus	1.3.6.1.4.1.534.6.6.8.7.3	the sensor connection status from slave unit 2 (0: No sensor connected 1: Sensor connected)
s3SensorStatus	1.3.6.1.4.1.534.6.6.8.7.4	the sensor connection status from slave unit 3 (0: No sensor connected 1: Sensor connected)
s4SensorStatus	1.3.6.1.4.1.534.6.6.8.7.5	the sensor connection status from slave unit 4 (0: No sensor connected 1: Sensor connected)
mTemperature	1.3.6.1.4.1.534.6.6.8.7.6	the temperature of master unit
s1Temperature	1.3.6.1.4.1.534.6.6.8.7.7	the temperature of slave unit 1
s2Temperature	1.3.6.1.4.1.534.6.6.8.7.8	the temperature of slave unit 2
s3Temperature	1.3.6.1.4.1.534.6.6.8.7.9	the temperature of slave unit 3
s4Temperature	1.3.6.1.4.1.534.6.6.8.7.10	the temperature of slave unit 4
mHumidity	1.3.6.1.4.1.534.6.6.8.7.11	the humidity of master unit
s1Humidity	1.3.6.1.4.1.534.6.6.8.7.12	the humidity of slave unit 1
s2Humidity	1.3.6.1.4.1.534.6.6.8.7.13	the humidity of slave unit 2
s3Humidity	1.3.6.1.4.1.534.6.6.8.7.14	the humidity of slave unit 3
s4Humidity	1.3.6.1.4.1.534.6.6.8.7.15	the humidity of slave unit 4
mVolAlarmA	1.3.6.1.4.1.534.6.6.8.8.1	the voltage alarm of phase 1 from master unit 1: Normal 2 : Low-voltage 3: Over-voltage
s1VolAlarmA	1.3.6.1.4.1.534.6.6.8.8.2	the voltage alarm of phase 1 from slave unit 1 1: Normal 2 : Low-voltage 3: Over-voltage
s2VolAlarmA	1.3.6.1.4.1.534.6.6.8.8.3	the voltage alarm of phase 1 from slave unit 2 1: Normal 2 : Low-voltage 3: Over-voltage
s3VolAlarmA	1.3.6.1.4.1.534.6.6.8.8.4	the voltage alarm of phase 1 from slave unit 3 1: Normal 2 : Low-voltage 3: Over-voltage
s4VolAlarmA	1.3.6.1.4.1.534.6.6.8.8.5	the voltage alarm of phase 1 from slave unit 4 1: Normal 2 : Low-voltage 3: Over-voltage
mVolAlarmB	1.3.6.1.4.1.534.6.6.8.8.6	the voltage alarm of phase 2 from master unit 1: Normal 2 : Low-voltage 3: Over-voltage
s1VolAlarmB	1.3.6.1.4.1.534.6.6.8.8.7	the voltage alarm of phase 2 from slave unit 1 1: Normal 2 : Low-voltage 3: Over-voltage
s2VolAlarmB	1.3.6.1.4.1.534.6.6.8.8.8	the voltage alarm of phase 2 from slave unit 2 1: Normal 2 : Low-voltage 3: Over-voltage
s3VolAlarmB	1.3.6.1.4.1.534.6.6.8.8.9	the voltage alarm of phase 2 from slave unit 3 1: Normal 2 : Low-voltage 3: Over-voltage
s4VolAlarmB	1.3.6.1.4.1.534.6.6.8.8.10	the voltage alarm of phase 2 from slave unit 4 1: Normal 2 : Low-voltage 3: Over-voltage
mVolAlarmC	1.3.6.1.4.1.534.6.6.8.8.11	the voltage alarm of phase 3 from master unit 1: Normal 2 : Low-voltage 3: Over-voltage
s1VolAlarmC	1.3.6.1.4.1.534.6.6.8.8.12	the voltage alarm of phase 3 from slave unit 1 1: Normal 2 : Low-voltage 3: Over-voltage
s2VolAlarmC	1.3.6.1.4.1.534.6.6.8.8.13	the voltage alarm of phase 3 from slave unit 2 1: Normal 2 : Low-voltage 3: Over-voltage

s3VolAlarmC	1.3.6.1.4.1.534.6.6.8.8.14	the voltage alarm of phase 3 from slave unit 3 1: Normal 2 : Low-voltage 3: Over-voltage
s4VolAlarmC	1.3.6.1.4.1.534.6.6.8.8.15	the voltage alarm of phase 3 from slave unit 4 1: Normal 2 : Low-voltage 3: Over-voltage
mCurAlarmA	1.3.6.1.4.1.534.6.6.8.9.1	the current alarm of phase 1 from master unit 1: Normal 2: Low-current 3: Over-load
s1CurAlarmA	1.3.6.1.4.1.534.6.6.8.9.2	the current alarm of phase 1 from slave unit 1 1: Normal 2: Low-current 3: Over-load
s2CurAlarmA	1.3.6.1.4.1.534.6.6.8.9.3	the current alarm of phase 1 from slave unit 2 1: Normal 2: Low-current 3: Over-load
s3CurAlarmA	1.3.6.1.4.1.534.6.6.8.9.4	the current alarm of phase 1 from slave unit 3 1: Normal 2: Low-current 3: Over-load
s4CurAlarmA	1.3.6.1.4.1.534.6.6.8.9.5	the current alarm of phase 1 from slave unit 4 1: Normal 2: Low-current 3: Over-load
mCurAlarmB	1.3.6.1.4.1.534.6.6.8.9.6	the current alarm of phase 2 from master unit 1: Normal 2: Low-current 3: Over-load
s1CurAlarmB	1.3.6.1.4.1.534.6.6.8.9.7	the current alarm of phase 2 from slave unit 1 1: Normal 2: Low-current 3: Over-load
s2CurAlarmB	1.3.6.1.4.1.534.6.6.8.9.8	the current alarm of phase 2 from slave unit 2 1: Normal 2: Low-current 3: Over-load
s3CurAlarmB	1.3.6.1.4.1.534.6.6.8.9.9	the current alarm of phase 2 from slave unit 3 1: Normal 2: Low-current 3: Over-load
s4CurAlarmB	1.3.6.1.4.1.534.6.6.8.9.10	the current alarm of phase 2 from slave unit 4 1: Normal 2: Low-current 3: Over-load
mCurAlarmC	1.3.6.1.4.1.534.6.6.8.9.11	the current alarm of phase 3 from master unit 1: Normal 2: Low-current 3: Over-load
s1CurAlarmC	1.3.6.1.4.1.534.6.6.8.9.12	the current alarm of phase 3 from slave unit 1 1: Normal 2: Low-current 3: Over-load
s2CurAlarmC	1.3.6.1.4.1.534.6.6.8.9.13	the current alarm of phase 3 from slave unit 2 1: Normal 2: Low-current 3: Over-load
s3CurAlarmC	1.3.6.1.4.1.534.6.6.8.9.14	the current alarm of phase 3 from slave unit 3 1: Normal 2: Low-current 3: Over-load
s4CurAlarmC	1.3.6.1.4.1.534.6.6.8.9.15	the current alarm of phase 3 from slave unit 4 1: Normal 2: Low-current 3: Over-load
mTemAlarm	1.3.6.1.4.1.534.6.6.8.10.1	the temperature alarm of master unit 1: Normal 2: Low-temperature 3:Over-temperature
s1TemAlarm	1.3.6.1.4.1.534.6.6.8.10.2	the temperature alarm of slave unit 1 1: Normal 2: Low-temperature 3:Over-temperature
s2TemAlarm	1.3.6.1.4.1.534.6.6.8.10.3	the temperature alarm of slave unit 2 1: Normal 2: Low-temperature 3:Over-temperature
s3TemAlarm	1.3.6.1.4.1.534.6.6.8.10.4	the temperature alarm of slave unit 3 1: Normal 2: Low-temperature 3:Over-temperature
s4TemAlarm	1.3.6.1.4.1.534.6.6.8.10.5	the temperature alarm of slave unit 4 1: Normal 2: Low-temperature 3: Over-temperature
mHumAlarm	1.3.6.1.4.1.534.6.6.8.10.6	the Humidity alarm of master unit 1: Normal 2: Low-Min humidity 3:Over-Max humidity

s1HumAlarm	1.3.6.1.4.1.534.6.6.8.10.7	the temperature alarm of slave unit 1 1: Normal 2: Low-Min humidity 3:Over-Max humidity
s2HumAlarm	1.3.6.1.4.1.534.6.6.8.10.8	the Humidity alarm of slave unit 2 1: Normal 2: Low-Min humidity 3:Over-Max humidity
s3HumAlarm	1.3.6.1.4.1.534.6.6.8.10.9	the Humidity alarm of slave unit 3 1: Normal 2: Low-Min humidity 3:Over-Max humidity
s4HumAlarm	1.3.6.1.4.1.534.6.6.8.10.10	the Humidity alarm of slave unit 4 1: Normal 2: Low-Min humidity 3:Over-Max humidity

3.7 TELNET ACCESS

The application of Telnet enables the user to remotely manage the EZ-PDU. The user can monitor and manage the device by entry the command line from the Telnet program. Telnet requires the the customer terminal from a PC. The main command lines are as following: STATUS、REBOOT、RESET、HELP

Status

The "STATUS" command line can be used to view the device states such as amps/volts/kWh or temp/humid.

Command form : STATUS 【INDEX】

【INDEX】 : 0 is master, 1-4 is slave

Example: status 0 : To view the amps/volts/kWh and temp/humid of the Master unit

Note: the actual value should be 10x of the displayed value

Reboot

Enter the REBOOT command line to restart the device.

Reset

Enter the RESET command line to restore to factory settings.

4. SPECIFICATIONS

Item		Parameters	
Input	Single phase	Rating voltage	110/220V 50/60HZ
		Max current	16A, 32A, 63A
	Three phase	Rating voltage	380V 50/60HZ
		Max current	3×16A, 3×32A
	Direct current	Rating voltage	240V /336V
		Max current	40A / 60A
	Cable Spec		16A : 3×1.5mm ² ×3M 32A : 3×6.0mm ² ×3M
Input terminal		16A input : 3×1.5mm ² ×2M IEC60320 C20 input 32A input : 3×6.0mm ² ×2M IEC60309 2P+E plug	
Overload protection		Circuit breaker (optional)	
Output	Single Phase	Rating voltage	110/220V
		Max current	16A, 32A, 63A
	Three Phase	Rating voltage	220V
		Max current	3×16A, 3×32A
	Direct Current	Rating voltage	240V /336V
		Max current	40A / 60A
Outlet standard		Optional	
Outlet quantity		Optional	
Display	Display method		2 groups of 3 way LCD display
	Display contents		Amps / volts / kWh / kW, IP address, address code, Temp/humid
	Accuracy	Voltage	Accuracy : ±1% +3 byte Resolution : 1V Respond time : 400ms Display method : LCD; Display direction: Vertical
		Current	Accuracy : ±1% +2 byte Resolution : 100mA Respond time : 400ms Display method : LCD; Display direction: Vertical
		kWh	Accuracy : ±1% Resolution : 0.1kWh Respond time : 400ms Display method : LCD; Display direction: Vertical
Physical Spec	Material		ABS + PC
	Color		Black
	Hot-Swap EZ-PDU module		180mm
Installation	Horizontal, Vertical		
Monitor	Total load current, Input voltage, Total energy consumption (kWh), Total Power (kW), Temp/Humid		
Setting	Threshold of Amps / Volts / Temperature and humidity		
	Email alarm address, HTTP, SNMP (V1), Network (IP, Gateway, Subnet Mask, DNS)		
Environment	Temperature	-5°C ~ 45°C	
	Relative humidity	30%~90%	
	Storage	-20°C ~70°C	
Alarm	System Default	When threshold of current is exceeded	
		When threshold of voltage is exceed	
	User defined alarm	When threshold of current is exceeded	
		When threshold of voltage is exceed	
		When threshold of temperature/humidity is exceeded	
	Alarm	Buzzer sounds	
Send E-mail to administrator automatically			
SNMP sends trap alerts			
Access	Web based, access via common web browsers		
	SNMP v1 support		
	Modbus (optional, request for this feature before production)		
User Management	User name and password configurable		

6. WARRANTY

2-Year Limited Warranty. Seller warrants this product, if used in accordance with all applicable instructions, to be free from original defects in material and workmanship for a period of 2 years from the date of initial purchase. If the product should prove defective in material or workmanship within that period, Seller will repair or replace the product, at its sole discretion.

THIS WARRANTY DOES NOT APPLY TO NORMAL WEAR OR TO DAMAGE RESULTING FROM ACCIDENT, MISUSE, ABUSE OR NEGLIGENCE OR OPERATION OUTSIDE THE ALLOWED ENVIRONMENT. SELLER MAKES NO EXPRESS WARRANTIES OTHER THAN THE WARRANTY EXPRESSLY SET FORTH HEREIN.

WARNING: The individual user should take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to the suitability or fitness of these devices for any specific application.

If you have questions about this product or need technical support, please contact us or visit our website.

ArcTiv Technologies, Ltd.

4F., No. 12, Ln. 345, Yangguang St.,
Neihu Dist., Taipei City 114 ,
Taiwan (R.O.C.)

sales@arctiv-tech.com

www.arctiv-tech.com



Latest Revision: November, 2021